


# **Sonic Hair Brush**

Vibrate massage

If you has a heart condition and pacemaker, please consult with doctor before using the device.



## Product Structure




## How to use

### Battery install


1. Remove the Battery Compartment Cover, and open the Waterproof Battery Compartment Cover by turning clockwise. Then install two AAA battery. (Fig 1)  
# Close the Waterproof Battery Compartment Cover with the coin.
2. After install the battery, place the waterproof cover to the arrow, and close it tightly. (Fig 2)  
# Make sure the cover tight enough to prevent water in.
3. Install the Battery Compartment Cover.





## How to use

1. Press Power button to turn on the comb and enjoy the head massage over.  
(Vibration about 8,600 times/min)
2. Please use the comb on the scalp.  
When using in the bathroom, please do not put the device into the water for long time.
3. Press Power button to turn off the comb.



When you open or close the cover, please make points A and B aligned according to the position in the picture, rotate in the direction of the arrow

Product Name : Sonic Hair Brush

Model No. : MAX-M01MC0365

Battery : 2 x 1.5V Alkaline AAA battery

Voltage : 3V

## **Cautions:**

- For adults only.
- Do not put this product into water or let water get into it.
- Do not drop or misuse this product.
- Do not leave this product unattended when working.
- Keep children and pets away from the movable parts of this product
- When in use, sliding or transporting, please ensure that there are no people or pets nearby to avoid accidents.
- Please use suitable battery to this product.
- Do not use unauthorized accessories.
- Please read this manual instruction carefully before operation.
- Any other usage that is not listed in this manual instruction is forbidden.
- Recommended usage time of this product is 10 minutes/ session.
- Please check if any part of this products is damaged before use. If so, please do not use it and contact us for repair.
- Please do not use it if the cover is broken or damaged.
- Please do not use it if the shell or surface is damaged.
- Please do not drop anything into this product.
- Please do not fall asleep while using this product.
- Please do not use it while driving.
- Please do not use it if drunk or feeling unwell.

**Please use 2 AAA battery.**

**Please do not use  
rechargeable batteries.**